
77-315 Removal and installation of rear window on cabriolet

Preliminary work: Removal and installation of headlining on convertible (77-055) Operation no. of operation texts and work units or standard texts and flat rates:





After removing headlining fasten rear window on the frame with a nut at the top center to prevent the window from swivelling down when the soft top bow is lowered and bending the frame in the soft top cover.

Retaining strips (arrows)	remove from intermediate layer on window
	frame, fasten.
Plug connection for heated window	disconnect, connect.
Soft top bow	lower (do not lock), put up.
Nuts (1)	unscrew, screw on.
Slider (2)	remove, install.
Soft top bow	put up, lower.
Nut (locating)	unscrew, screw on.
Rear window	remove from frame, install.



When removing and installing or replacing the rear window use a new gasket.

The gasket should be 1 mm lower than the top edge of the glass when glued onto the window frame.

Tighten nuts uniformly to prevent waves in gasket.