



Mercedes-Benz

service information

TO: OUR MERCEDES-BENZ PASSENGER CAR DEALERS

DATE: December 1992 (supersedes S.I. MBNA 82/55a, Oct. 1991) **REF. NO.** MBNA 82/55b

Revision: to all W.I.'s, NAM programming for Models 129/140 and new W.I. 281.

SUBJECT: ALL M.Y. 1992 MODELS
MERCEDES-BENZ INTEGRATED CELLULAR TELEPHONE

Attached to this Service Information are four separate Work Instructions

- W.I. 263: MODELS 124, 201
INSTALLATION OF CELLULAR TELEPHONE SYSTEM
- W.I. 281: MODEL 124.066
INSTALLATION OF CELLULAR TELEPHONE SYSTEM
- W.I. 264: MODELS 129, 140
INSTALLATION OF CELLULAR TELEPHONE SYSTEM
- W.I. 266: MODELS 124, 129, 201
SUBSEQUENT INSTALLATION OF TRI-BAND ANTENNA

and one sample copy each of the

- Cellular Telephone NAM Programming Guide for Model 124, 201
- Cellular Telephone NAM Programming Guide for Model 129, 140
- Certificate of Cellular Telephone Installation/Warranty Registration.

Also enclosed with this Service Information is one packet each of the above three items.

Form Number	Description
S-2499-091	Cellular Telephone NAM Programming Guide for Model 124, 201
S-2503-91B	Cellular Telephone NAM Programming Guide for Model 129, 140 (for use with version I transmitter-receiver)
S-2503-092	Cellular Telephone NAM Programming Guide for Model 129, 140 (for use with version II transmitter-receiver)
S-2488-A92	Certificate of Cellular Telephone Installation/Warranty Registration

Additional copies of the above three items may be ordered from Service and Parts Literature via the M-B NET System.

Work Instructions #263 and 264 describe the detailed procedure for installing a Mercedes-Benz integrated cellular telephone system in any vehicle as of M.Y. 1992.

Note:

With the introduction of model year production startup, all M.Y. 1992 vehicles are prewired for cellular telephones. Models 129.076 (600SL), 140.057 (600SEL) and 140.076 (600SEC) are pre-equipped with a cellular telephone from the VPC and merely require NAM Programming.

On MY 1992 vehicles up to the chassis end numbers listed in the table below, the tri-band antenna was not installed in production.

Subsequent installation of the tri-band antenna should **only** be performed when a customer requests installation of an MB integrated cellular telephone.

Work Instruction #266 describes the procedure for retrofitting a tri-band antenna (AM/FM/Cellular).

Effective Serial Number

Model	As of Chassis End Number
W201	1F 887 607
W/C124	As of end of July 1992
S124	1F 194 110
R129	1F 039 252

IMPORTANT!

The Certificate of Cellular Telephone Installation/Warranty Registration **MUST BE FILLED OUT** and distributed as per the instructions.

The pink copy of the Certificate of Cellular Telephone Installation/Warranty Registration must be mailed to:

**Mercedes-Benz of North America, Inc.
One Mercedes Drive
Montvale NJ 07645
Attn: Warranty Department**

in order to register the cellular telephone. If the card is not filled out and mailed in, future warranty claims for the telephone will be denied.

A telephone Installation Kit parts listing is included at the end of each Work Instruction. To order individual pieces of the telephone kits for replacement purposes, please refer to the Parts Information binder.